



## Obsidian & Glass Elements Installation Guidelines

1. Apply a premium grade WHITE thin-set mortar using a 3/16 inch V-notch trowel. Either modified or unmodified thin-set may be used.
2. Set tiles, apply pressure or tap the surfaces with a rubber grout float to ensure all tiles are bonded and aligned properly. Use a level periodically to check the grout joints.
3. After 24 hours, mix and apply UNSANDED GROUT. It is very important to understand that any abrasive materials or chemicals can scratch the surface of glass tile.
4. Clean all excess grout immediately with a damp sponge. After 12 hours polish any remaining grout haze with a clean dry cloth.

### Additional information:

- A premium glass diamond blade is recommended for glass cutting.
- Glass tiles can be routinely cleaned with any non-abrasive cleaning compound or formula that is recommended for both glass and stone. Please follow manufacturer's instructions when using these products.